

ESPAR HEATER MODIFICATION INFORMATION BULLETIN

UP 054 REV 1 2010-04-01

Page 1 of 1

AMBULANCE TYPE: MX151D 2009

ISSUE

This bulletin is to inform owners of Demers Ambulances that a modification of the Espar heater activation is required as per BCAS request. The Espar heater should only work when the engine is running.


ACTION

Perform the modification as per the attached documentation. The modification can be performed during any scheduled 'A' Service Safety Inspection.


SERVICE PROCEDURE

Modification time: 0.5 hour / per vehicle.

Qty.	Description
1	ESPAR WIRE



BEFORE PROCESSING MODIFICATION, LOCATE THE FUSE BOX FU6 IN ELECTRICAL PANEL.



LOCATE AND REMOVE THE 10 AMP FUSE IN POSITION 7 OF THE FU6 FUSE BOX.




LE :	ESPAR HEATER ACTIVATION
	MODIFICATION

 # DRAWING : REV : 1
00646 PAGE : 1/6



TO REMOVE THE CONSOLE PANEL, LOCATE AND UNSCREW THE SIX (6) SCREWS AS SHOWN.



REMOVE THE REAR CONSOLE TO HAVE ACCESS TO THE HEATER SWITCH AND RELAY.




TITLE :	ESPAR HEATER ACTIVATION
	MODIFICATION

DATE : 29/04/2010 DRAW. : Y. DUBÉ B. LANDRY

DRAWING : REV : 1

00646 PAGE: 2/6






TITLE : **ESPAR HEATER ACTIVATION MODIFICATION**

DRAW.: 29/04/2010


Y. DUBÉ B. LANDRY

DRAWING :

00646



LOCATE THE RED-BLACK WIRE (FU6-A7) FROM THE SPARE SWITCH.





ESPAR HEATER ACTIVATION MODIFICATION

DATE: 29/04/2010 DRAW.: Y. DU

Y. DUBÉ B. LANDRY


DRAWING : REV : 1

00646

PAGE: 4/6


CONFIGURATION "A"

BEFORE MODIFICATION



LOCATE AND REMOVE THE YELLOW WIRE (ESP1) IN POSITION 86 FROM THE RELAY SUPPORT.


AFTER MODIFICATION



- 1 ISOLATE AND INSULATE THE YELLOW WIRE TERMINAL (ESP1) WITH HEAT SHRINK TUBING.
- 2 CONNECT THE NEW RED/BLACK WIRE (FU6-A7) IN POSITION 86 OF THE RELAY SUPPORT.


CONFIGURATION "B"

BEFORE MODIFICATION



LOCATE AND REMOVE THE YELLOW WIRE (ESP1) IN POSITION 86 FROM THE RELAY SUPPORT.

AFTER MODIFICATION



- 1 ISOLATE AND INSULATE THE YELLOW WIRE TERMINAL (ESP1) WITH HEAT SHRINK TUBING.
- 2 CONNECT THE NEW RED/BLACK WIRE (FU6-A7) IN POSITION 86 OF THE RELAY SUPPORT.

THE INFORMATION, TECHNICAL DATA AND STANDARDS DESCRIBED HEREIN ARE THE EXCLUSIVE PROPERTY OF DEMERS AMBULANCES AND/OR CONTAIN PROPRIETARY RIGHTS OF OTHERS AND ARE NOT TO BE USED OR DISCLOSED TO OTHERS WITHOUT THE WRITTEN AGREEMENT OF DEMERS AMBULANCES.



TITLE : **ESPAR HEATER ACTIVATION MODIFICATION**

DRAW.: 29/04/2010


Y. DUBÉ B. LANDRY

DRAWING :

00646



REINSTALL THE CONSOLE PANEL.



REINSTALL THE 10 AMP FUSE IN THE FU6 FUSE BOX.



TITLE :	ESPAR HEATER ACTIVATION
	MODIFICATION

DATE : 29/04/2010 DRAW. : Y. DUBÉ B. LANDRY

DRAWING : REV :

00646 PAGE: 6/6

1