

# STEPWELL REINFORCEMENT SERVICE BULLETIN

UP 067 REV 2 2010-09-27

Page 1 of 1

AMBULANCE TYPE: MX160 (2009-2010)

#### **ISSUE**

This bulletin is to inform owners of Demers Ambulances that a reinforcement of the side entry door step well and/or spare tire compartment is required. During the manufacturing process of the module, some step wells were not welded properly.

#### **ACTION**

Reinforcement of the side entry door step well and/or spare tire compartment is required during the next service scheduled.

Perform the modification as per the attached documentation.

#### **SERVICE PROCEDURE**

Modification time: 0.5 hour / per vehicle.


Qty.	Description	Demers Part #			
11	screw	E008009			

Complete a Warranty form & order components on the specified sheet. Forward order to the Demers Customer Assistance Centre service department by fax at: 1-306-373-4144, by email at: <a href="mailto:parts@advancedresponsevehicles.com">parts@advancedresponsevehicles.com</a> or by phone at: 1-877-373-4464. If you have any questions, contact our Demers Customer Assistance Centre service department at following phone number 1-877-373-4464 and ask for John-Paul Thauberger. You may also contact Demers by fax at: 1-450-467-6526, by email at: <a href="mailto:dchatelle@demers-ambulances.com">dchatelle@demers-ambulances.com</a> or by phone at: 1-800-363-7591.

### To make modifications, two methods can be applied.

Option 1 (Prefered): Weld the components.

Option 2 (If aluminium welding not possible): Fasten with screws the components.





Remove the yellow carpet and clean the surfaces to be welded.

THE INFORMATION, TECHNICAL DATA AND STANDARDS
DESCRIBED HEREIN ARE THE EXCLUSIVE PROPERTY OF DEMERS
AMBULANCES AND/OR CONTAIN PROPRIETARY RIGHTS OF
OTHERS AND ARE NOT TO BE USED OR DISCLOSED TO OTHERS
WITHOUT THE WRITTEN AGREEMENT OF DEMERS AMBULANCES.



III LL .	
	STEP WELL REINFORCEMENT

Y. DUBÉ

DATE : **2011-02-18** 

# DRAWING :


REV:

# 00679

PAGE: 1/6



Install a protective cover.



Mark location to solder as shown on picture.

THE INFORMATION, TECHNICAL DATA AND STANDARDS
DESCRIBED HEREIN ARE THE EXCLUSIVE PROPERTY OF DEMERS
AMBULANCES AND/OR CONTAIN PROPRIETARY RIGHTS OF
OTHERS AND ARE NOT TO BE USED OR DISCLOSED TO OTHERS
WITHOUT THE WRITTEN AGREEMENT OF DEMERS AMBULANCES.




IILL .	
	STEP WELL REINFORCEMENT

Y. DUBÉ


DATE : DRAW. : 2011-02-18

# DRAWING: # 00679

PAGE: 2/6



Weld the components.



Make sure that the welds are in the same place as shown on picture.

THE INFORMATION, TECHNICAL DATA AND STANDARDS
DESCRIBED HEREIN ARE THE EXCLUSIVE PROPERTY OF DEMERS
AMBULANCES AND/OR CONTAIN PROPRIETARY RIGHTS OF
OTHERS AND ARE NOT TO BE USED OR DISCLOSED TO OTHERS
WITHOUT THE WRITTEN AGREEMENT OF DEMERS AMBULANCES.



1166.	
	STEP WELL REINFORCEMENT


Y. DUBÉ


DATE: DRAW.:

# DRAWING :

: REV:

# 00679 PAGE: 3/6





Put the screws (11) ""tek" pan square # 10 x ¾ zp" in the same location shown on picture.

THE INFORMATION, TECHNICAL DATA AND STANDARDS DESCRIBED HEREIN ARE THE EXCLUSIVE PROPERTY OF DEMERS AMBULANCES AND/OR CONTAIN PROPRIETARY RIGHTS OF OTHERS AND ARE NOT TO BE USED OR DISCLOSED TO OTHERS WITHOUT THE WRITTEN AGREEMENT OF DEMERS AMBULANCES.



IIILL .	
	STEP WELL REINFORCEMENT


DRAW.: 2011-02-18

Y. DUBÉ # 00679


# DRAWING :

REV: 1 PAGE :

4/6



Make sure that all screws are installed through the two aluminium edges.



Put " RUBBERIZED UNDERCOAT " on the screws.

THE INFORMATION, TECHNICAL DATA AND STANDARDS
DESCRIBED HEREIN ARE THE EXCLUSIVE PROPERTY OF DEMERS
AMBULANCES AND/OR CONTAIN PROPRIETARY RIGHTS OF
OTHERS AND ARE NOT TO BE USED OR DISCLOSED TO OTHERS
WITHOUT THE WRITTEN AGREEMENT OF DEMERS AMBULANCES.



TITLE:

STEP WELL REINFORCEMENT

DATE: 2011-02-18 DRAW.:

Y. DUBÉ

# DRAWING :

NG: REV:


# 00679

PAGE: 5/6

#### Apply the same methods for G3 compartment

Option 1 (Prefered): Weld the components.

Option 2 (If aluminium welding not possible): Fasten with screws the components.



Weld the components.



Apply the same method as the step well.

THE INFORMATION, TECHNICAL DATA AND STANDARDS
DESCRIBED HEREIN ARE THE EXCLUSIVE PROPERTY OF DEMERS
AMBULANCES AND/OR CONTAIN PROPRIETARY RIGHTS OF
OTHERS AND ARE NOT TO BE USED OR DISCLOSED TO OTHERS
WITHOUT THE WRITTEN AGREEMENT OF DEMERS AMBULANCES.



ITLE :			
	STEP WELL	REINFOR	CEMEN

Y. DUBÉ

2011-02-18

# DRAWING : # 00679

REV: 1

/9 PAGE: 6/6



## Formulaire de réclamation de garantie Warranty claim form

AQ-F-SC.1 rev.2

Page 1 de 1

1	Numéro de série du véhico Vehicle serial number (V.I.							
2	Numéro d'unité de la flotte Fleet unit number					numéro Stock stock number		
4	Date de mise en service (ADate in service (YY/MM/DD)	A/MM/JJ)			Kilomètr Milles / I	res / kilometres Miles	3	
6	Date du bris (AA/MM/JJ) Date of failure (YY/MM/DD)					la demande ga warranty claim		
8		Description du	problème / [	Descrip	tion of t	he problem		
9		Cause(s) du	problème / 0	Cause(	s) of the	problem		
10		Action(s) co	orrective(s) /	Correc	ctive(s) a	action(s)		
11	Temps évalué pour la rép Time evaluated for repair							
12	Demande de réclamation Claim requested by	faite par			1 2	N° facture Invoice N°		
Adresse de facturation / Billing address  Tél. / Phone:  Tél. / Phone:  Tél. / Phone:								
N°	pièces / Part N° QTY			DE	SCRIP	TION		
1	SÉCTION RÉSERVÉE DEMERS RESERVED SECTION							
1.	,							
2.								
3.	Date d'autorisation de gara	intie / Warranty c	ciaim authoriz	ation o	ate:			