

ESPAR RELOCATION SERVICE BULLETIN

UP 074 REV 2 2011-05-03

Page 1 of 1

AMBULANCE TYPE: MX151D 2009 (Unit 62800 to Unit 62899)

ISSUE

This bulletin is to inform owners of Demers Ambulances that a relocation of the Espar heating unit is required. The installation of the Espar heating unit needs to be relocated in order to meet BCAS requirement.

ACTION

Relocation of the Espar heating unit is required at the next scheduled 'A' service safety inspection.

Perform modification as per the attached documentation.


SERVICE PROCEDURE

Installation time: 3.5 hour / per vehicle.

Qty.	Description	Demers Part #
1	Template	D018934
2.5 ft	Flexible hoses	E312023
1	Installation kit	E710206

Complete a Warranty form & order components on the specified sheet. Forward order to the Demers Customer Assistance Centre service department by fax at: 1-306-373-4144, by email at: parts@advancedresponsevehicles.com or by phone at: 1-877-373-4464. If you have any questions, contact our Demers Customer Assistance Centre service department at following phone number 1-877-373-4464 and ask for John-Paul Thauberger.

You may also contact our authorized Demers Service Dealer (Knight Hill Automotive) by fax at: 1-604-273-1848, by email at: contact@knighthill.com or by phone number at: 1-888-546-8333.






TITLE :

ESPAR RELOCATION

DRAW.: 2011-08-17 Y. DUBÉ # DRAWING :


00699

1/9



To remove the panel, remove the silicone seals. 1- Push the panel upwards, 2 - then pull the bottom part out.


3- push the panel down to remove it.




Locate and remove the suction pump.



Remove the air heater fuel metering pump.



Disconnect the hot air outlet and the air inlet.



Locate the air heater's fuel metering pump.



Remove the air heater with the support.



TITLE :

ESPAR RELOCATION

Y. DUBÉ

ATE : 2011-08-17 # DRAWING : # 00699

REV:

PAGE: 2/9



The air heater with the support has been removed.



Disconnect the combustion air inlet and the exhaust outlet.



Remove the 4 nuts to remove the air heater from the support.



Remove the fuel metering pump hose.

Send the fuel metering pump hose under the vehicle back through the floor.



Send the combustion air inlet and the exhaust outlet under the vehicle back through the floor.



The air heater has been removed from the support.




TITLE: ESPAR RELOCATION

Y. DUBÉ


2011-08-17

DRAWING : # 00699

PAGE: 3/9




Place the template # D018934 and mark as shown on picture.



Use provided gasket to mark the air heater hole as shown on picture.



Install the provided plate with the 4 nuts.



Use a Dremel Multi-Max tool (or equivalent) to cut and remove floor covering and plywood (Not the metal).

Cut and remove the aluminum floor.

Remove the guide.

Use a vacuum cleaner to remove all foreign material.



Install the provided gasket.

THE INFORMATION, TECHNICAL DATA AND STANDARDS
DESCRIBED HEREIN ARE THE EXCLUSIVE PROPERTY OF DEMERS
AMBULANCES AND/OR CONTAIN PROPRIETARY RIGHTS OF
OTHERS AND ARE NOT TO BE USED OR DISCLOSED TO OTHERS
WITHOUT THE WRITTEN AGREEMENT OF DEMERS AMBULANCES.



TITLE:

ESPAR RELOCATION

Y. DUBÉ

ATE : 2011-08-17 # DRAWING : # 00699

REV:


PAGE: 4/9



Place the air heater in the new location.



Use 4 provided screws to fix the air heater on the floor.



Remove the terminals on the connector from the fuel metering pump power harness.



Pass the fuel metering pump power harness through the new hole.



Place the suction pump as shown on picture to mark the new holes.



Mark the 4 new holes.



TITLE :

ESPAR RELOCATION

Y. DUBÉ

ATE: DRAW.: 2011-08-17

DRAWING :

00699


PAGE: 5/9



Drill 9/64" all the way through the metal.




Manually install the rubber bushings in the holes.




Use original nuts to fix the suction pump on the wheel well.




Seal the hole.





Modify the hot air outlet as shown on picture.



Modify the fuel metering pump hose, the combustion air inlet and the exhaust outlet as shown on picture.



TITLE : **ESPAR RELOCATION**

Y. DUBÉ

2011-08-17

DRAWING : #00699

PAGE :


6/9



Reconnect the hot air outlet.



Reconnect the air inlet.



NOTE:		



TLE:	
	ESPAR RELOCATION


Y. DUBÉ

ATE: DRAW.: 2011-08-17

DRAWING : # 00699

REV:

PAGE: 7/9





IILE:	
	ESPAR RELOCATION

2011-08-17

DRAW.: # DRAWING :

Y. DUBÉ # 006

00699 PAGE: 8/9



Reconnect the hot air outlet and the air inlet on the panel.

Reinstall the panel. Apply silicone.



Note: The "MASTER" switch must be ON and the engine must be running to activate the Espar heating system.

Test Espar by putting heat on thermostat and turning on heat switch.

Espar may require a couple of minutes to start.

NOTE:

THE INFORMATION, TECHNICAL DATA AND STANDARDS
DESCRIBED HEREIN ARE THE EXCLUSIVE PROPERTY OF DEMERS
AMBULANCES AND/OR CONTAIN PROPRIETARY RIGHTS OF
OTHERS AND ARE NOT TO BE USED OR DISCLOSED TO OTHERS
WITHOUT THE WRITTEN AGREEMENT OF DEMERS AMBULANCES.



TITLE:

ESPAR RELOCATION

Y. DUBÉ

DATE: 2011-08-17

DRAWING : # 00699

PAGE: 0/

9/9



Formulaire de réclamation de garantie Warranty claim form

AQ-F-SC.3 rev.0

Page 1 de 1

1	Numéro de série du véhicule (Coin gauche Vehicle serial number (V.I.N) (Number on d						
2	Numéro d'unité de la flotte Fleet unit number				s numéro Stoc s stock numbe		
4	Date de mise en service (AA/MM/JJ) Date in service (YY/MM/DD)		-	Kilomè Milles /	tres / kilometre / Miles	es	
6	Date du bris (AA/MM/JJ) Date of failure (YY/MM/DD)				e la demande f warranty clair		
8	Description	du problème	/ Descrip	tion of	the problem		
9	Cause(s)	du problème	/ Cause(s) of th	e problem		
	9 Cause(s) du problème / Cause(s) of the problem						
10	Action(s) corrective(s	s) / Correc	ctive(s)	action(s)		
	Temps évalué pour la réparation						
11	Time evaluated for repair						
12	Demande de réclamation faite par Claim requested by			13 N° facture Invoice N°			
14	Adresse de facturation / Billing add	dress	15	Adre	esse de livraiso	on / Shipping	address
Т	Tél. / Phone:						
N°	N° pièces / Part N° QTY DESCRIPTION						
	<u> </u>						
	SÉCTION RÉSERVÉE DEMERS RESERVED SECTION						
1.	No. d'autorisation de garantie / Warranty claim authorization no. :						
	,						
2.	Temps alloué pour la réparation / Time a	allowed for rep					