

 BC Ambulance Service BC Emergency Health Services	Patient Compartment Pull-Out Step Maximum Load Decal	August 28, 2017 Page 1 of 1
AMBULANCE TYPE:	Demers	
UNITS AFFECTED:	63100 to 63369	

ISSUE: Load Limit Rating on patient compartment pull-out step has been increased.

The right side patient compartment pull-out step's load limit was reviewed and has been increased from a maximum load of 250 lb to 400 lb. The load limit decal needs to be changed to reflect the new rating.

ACTION: Replace With Supplied Upgraded Decal – Maximum Load 400 lb

LABOUR TIME: .1 hr

SERVICE PROCEDURE:

- 1) Confirm the decal on the right side patient compartment pull-out step reads "Maximum Load 250 lb."
- 2) Remove this decal using an appropriate scraper – be careful not to damage the paint on the step assembly.
- 3) Clean the surface of the step and apply the upgraded decal in the same position as the old decal.

