

 <b>BC Ambulance Service</b> BC Emergency Health Services	<h2>Yellow Grab Handle Removal</h2>	May 14, 2018 Page 1 of 1
<b>AMBULANCE TYPE:</b>	<b>Demers and Crestline</b>	
<b>UNITS AFFECTED:</b>	<b>All Units Equipped with a Yellow Grab Handle Inside the Left Rear Door</b>	

**ISSUE:** The yellow grab handle located inside the left rear door interferes with the patient when loading or unloading.

**ACTION:** At the next scheduled "A" service, remove the yellow grab handle and discard.

**LABOUR TIME:** 0.2 HRS

**BILL TO:** BC Ambulance

**PARTS:** Push Retainer Pins - Lordco P/N: 18771 and clear Silicone.



**SERVICE PROCEDURE:**

1. Identify the yellow grab handle inside the left rear door. Refer to picture below.



2. Using the appropriate tools, remove the handle.
3. Plug the exposed bolt holes with the push retainer pins ordered from Lordco, or equivalent parts supplier P/N: 18771. Apply a small amount of clear silicone to the push pins to further secure the push pins.
4. Dispose of the removed handle.