

	<b>POWER STEERING RESERVOIR SUPPLY HOSE SERVICE BULLETIN</b>	<b>UP 110 REV 3 2014-06-12</b>
		<b>Page 1 of 3</b>

AMBULANCE TYPE: MX151D – MX163D

<b>BCAS UNIT</b>
<b>62911-92979</b>
<b>63030-63079</b>
<b>63080-63092</b>
<b>63100-63149</b>
<b>63160-63164</b>

## ISSUE

This bulletin is to inform owners of Demers Ambulances that a modification of the Power Steering reservoir hose is required. It has been brought to our attention that the power steering supply hose that is secured to the steering column has potential to rub through the column support rib. (See photos attached)

## ACTION

Modification of the failed transfer hose from the power steering reservoir to the pump is required during the next regular service scheduled. Please perform the modification as per the attached documentation.

The original power steering hose is about 20" long and too short to reroute, Purchase 28" of 5/8 hose from Lordco (part # H10110) or equivalent. To complete the repair drain the reservoir, replace the hose routing and fastening as detailed in the picture. Re-bleed the power steering system and check for leakage and interference.

**NOTE: Please make sure the hose is routed in such a way that it will not rub against accessory drive belt (like the alternator belt).**

## SERVICE PROCEDURE

Modification time: .5 hour / per vehicle.

### **Please note:**

With our new paperless warranty system no form is required to be filled out as these recalls are pre-approved for the time allotted, please fax your invoice to Demers Customer Assistance Centre service department at: 1-306-373-4144.

\*Please be sure to indicate the service bulletin number on the invoice.

Should you require additional time or have questions please call our Demers Customer Service Centre toll free at **1-877-373-9789**.



